



Landscaper Series

Jet Agitation MIXING INSTRUCTIONS

1. Check fuel and engine oil levels and fill if necessary.
2. Make sure all ball valves are closed.
3. Start engine and allow to warm up.
4. Fill the tank with water until 3/4 full.
5. Open the ball valves to run clear water through the hoses to help reduce the risk of clogs.
6. Turn off the valves and start loading your materials
7. Load materials into the tank in the following order.
 - a. Load all soluble or liquid nutrients and growth enhancer such as fertilizer, lime, bio-stimulant, etc.
 - b. Load Dye if desired.
 - c. Load 1/2 of the mulch.
 - d. Load the seed.
 - e. Load Moisture Retention Polymers and Tackifiers
 - f. Load the remainder of the mulch.
8. Top off with water and continue mixing until thoroughly mixed.
9. You are now ready to spray.
10. Once you are done spraying, fill with 1/4 tank of water and flush the pump and hoses.
11. If you have additional tanks to spray, repeat process starting with step #4.
12. If you are done for the day, remove the drain plug and drain everything out of the tank, pump, hoses, etc.

